




[Frame 1]

Phase 1 – F1 interface bring-up

F1 Setup Request (gNB-DU odu0 -> gNB-CU). Before any UE can be served, the DU must register with the CU. The DU advertises its identity (gNB-DU-ID 0) and its full served-cell configuration: PLMN 00f110, cell NR-CGI 0000019b00, PCI 1, 5GS-TAC 7, plus the frequency, SSB and system-information layout. No UE context exists yet – this is pure interface management, and every UE-associated procedure below depends on it succeeding.

[Frame 2] F1 Setup Response (gNB-CU ocudu01 -> gNB-DU). The CU accepts the association and returns its name plus the Cells-to-be-Activated list (the served cells it authorises the DU to switch on). F1 is now up. Everything from here to frame 30 rides on this single association; it is torn down at the very end (frames 31-32).

[Frame 3]

Phase 2 – RRC connection setup

Initial UL RRC Transfer (DU -> CU), carrying the UE's **RRCSetupRequest**. The UE sent this on the radio CCCH; the DU received it, allocated a gNB-DU-UE-F1AP-ID (0) and a C-RNTI (17921), and forwards it – with the serving NR-CGI – up to the CU. This is the first UE-associated message and it opens the UE's context on the CU side. Note the DU UE id: it is the one identifier present on **every** UE message through release, which is why the per-UE session keys on it.

[Frame 4] DL RRC Transfer (CU -> DU), carrying **RRCSetup**, on SRB0 . The CU admits the UE and sends the RRCSetup that moves it off the CCCH and establishes signalling radio bearer SRB1 . From the next message onward all RRC travels on SRB1.

[Frame 5] UL RRC Transfer (DU -> CU), carrying **RRCSetupComplete** on SRB1 – and piggybacked inside it, the UE's first NAS message: a **5GMM Registration Request** (NAS 0x41 , still sent in the clear). This is the moment the RRC connection becomes useful: it delivers the UE's registration attempt to the AMF behind the CU. Everything in Phase 3-4 below is the AMF authenticating and securing that registration, relayed transparently over F1.

[Frame 6]

Phase 3 – NAS authentication (relayed as DL/UL Information Transfer)

DL RRC Transfer (CU -> DU): RRC **DL Information Transfer** carrying a NAS **Authentication Request** (0x56 , plaintext). The AMF challenges the UE. The CU is just a NAS pipe here – it wraps the AMF's NAS PDU in RRC and hands it to the DU for radio delivery.

[Frame 7] UL RRC Transfer (DU -> CU): RRC **UL Information Transfer** carrying the NAS **Authentication Response** (0x57 , plaintext). The UE answers the challenge. Authentication succeeds, which is what lets the network derive keys and turn on security next.

[Frame 8]

Phase 4 – NAS security activation


DL RRC Transfer (CU -> DU): NAS **Security Mode Command** (0x5d) . Its NAS security header is type 3 – *integrity-protected with a new 5G security context* – the hinge of the whole flow: from here the network expects NAS to be protected with the freshly derived keys.


[Frame 9] UL RRC Transfer (DU -> CU): the UE's NAS **Security Mode Complete**. This is the first message under the new context – NAS security header type 4, *integrity-protected and ciphered with the new context* – so Wireshark can no longer decode the inner NAS type, only confirm it is protected. NAS security is now active; every NAS PDU after this (frames 15-18, 27-28) is ciphered.

[Frame 10]

Phase 5 – AS security and UE context at the DU

UE Context Setup Request (CU -> DU). NAS security is up; now the CU builds the UE's **radio** context on the DU. This F1





[Frame 21] DL RRC Transfer (CU -> DU): RRC **RRCReconfiguration** on SRB1 . This is the UE-facing half of the DRB addition from frame 19 — it reconfigures the UE with the new bearer and radio parameters.

[Frame 22] UL RRC Transfer (DU -> CU): RRC **RRCReconfigurationComplete**. The UE has applied the new configuration. Registration plus default-bearer setup is now functionally complete; the UE is connected with a usable DRB.

[Frame 23]
Phase 9 — Public Warning System broadcast
Write-Replace Warning Request (CU -> DU), carrying **SIB6**. This is *non-UE-associated* — it concerns the cell, not our UE. The CU pushes an ETWS primary notification (**SIB6**) for the DU to broadcast, asking for 65535 repeats at a 10s period.

[Frame 24] Write-Replace Warning Response (DU -> CU). The DU acknowledges and reports the cells now broadcasting the warning.

[Frame 25] Write-Replace Warning Request (CU -> DU), carrying **SIB7** — the ETWS *secondary* notification (the actual warning content), companion to the SIB6 primary in frame 23.

[Frame 26] Write-Replace Warning Response (DU -> CU). Second PWS acknowledgement; the ETWS broadcast is fully armed on the cell. The UE-associated flow resumes below.

[Frame 27]
Phase 10 — final ciphered NAS
UL RRC Transfer (DU -> CU): a ciphered UL NAS PDU (security header type 2) — a late uplink NAS transaction from the UE before teardown. Ciphered; role-only.

[Frame 28] DL RRC Transfer (CU -> DU): the ciphered DL NAS reply. This closes the NAS dialogue; what follows is teardown.

[Frame 29]
Phase 11 — UE context release
UE Context Release Command (CU -> DU) with Cause : **radioNetwork normal-release** . The CU tells the DU to release this UE's context and radio resources — an orderly release (not a failure), consistent with a scripted registration-then-teardown capture.

It also embeds the UE's final RRCRelease , but as an opaque RRCContainer (00071000ff6c1afc) rather than a decoded message — Wireshark parses the RRC-Container inside a DL/UL RRC Transfer but not inside a Release Command. Those bytes are a PDCP PDU (SN 7) whose 1000 payload is a DL-DCCH rrcRelease plus its 4-byte MAC-I, in the clear because AS ciphering here is NEA0 (null). So the RRCRelease **is** delivered to the UE — embedded in the release command, not sent as its own message.

[Frame 30] UE Context Release Complete (DU -> CU). The DU confirms the UE's context and resources are freed. The per-UE F1 session that opened back at frame 3 ends here.

[Frame 31]
Phase 12 — F1 interface teardown
F1 Removal Request (Transaction 2) . With the UE gone, the F1 *interface* itself is torn down. Note: TS 38.473 lets **either** node initiate F1 Removal, and this exported-PDU capture carries no transport to prove which — it is drawn DU -> CU here (see the FXT header note).

[Frame 32] F1 Removal Response (Transaction 2) . The peer confirms removal; the F1 TNL association from frame 1 is gone. A new F1 Setup would be required before any further CU/DU signalling. End of capture.